



Operating instruction

Bottle refrigerator

Content

Model type	3
Explanation symbols	4
General information	4
Manufacturer's responsibility	5
General safety instructions and warnings	6
1. Standards and directives.....	8
2. Rating plate	9
3. Unpacking, installing and connecting	10
4. Temperature control.....	12
5. Temperature regulator	13
5.1. Mechanical thermostat	14
5.2. Eliwell electronic temperature controller	16
5.3. Danfoss electronic temperature controller	17
5.4. Elitech electronic temperature controller	18
5.5. Carel electronic temperature controller.....	19
6. Lighting control (optional).....	20
7. Loading	22
8. Maintenance, defrosting and cleaning.....	23
9. Service	23
10. Storage	25
11. Disposal	26
12. Information on the type of refrigerants and foam blowing agents	26
13. Possible malfunctions and their elimination	28







Model type

Model	External dimensions, mm HxWxD	Volume*, l	Nominal load per shelf, kg	Net weight , kg
"Ice Stream" Dragon	1870x420x470	181	12	65
"Ice Stream" Virgo	2000x395x485	185	12	72
"Ice Stream" Pearl	2000x465x485	196	14	78
"Ice Stream" SLine	1980x595x590	325	28	90
"Ice Stream" SmartCool 350	2073x590x590	325	28	90
"Ice Stream" Falcon	2075x590x590	392	28	105
"Ice Stream" Dynamic	2145x680x710	527	40	123
"Ice Stream" Leader	2155x765x820	725	70	170
"Ice Stream" Medium	2140x680x680	491	39	115
"Ice Stream" Force	2130x455x670	345	20	90
"Ice Stream" Prime	2155x750x820	725	70	165
"Ice Stream" Omega	2145x835x793	820	68	175
"Ice Stream" Vega	2145x835x795	747	70	160
"Ice Stream" Ideal Large	2195x905x685	787	72	132
"Ice Stream" Large	2145x1170x670	827	40	205
"Ice Stream" Active Large	2265x1170x670	953	40	215
"Ice Stream" Super Large	2055x1300x785	1089	50	220
"Ice Stream" Extra Large	2170x1300x785	1222	56	245
"Ice Stream" Large Lean	2145x1170x670	827	40	215
"Ice Stream AD" Energy	2100x764x820	686	68	160
"Ice Stream" Mega Large	2100x1540x670	1325	56	260
"Ice Stream" Bird	1670x490x685	274	28	77
"Ice Stream" Is Mini 50	520x467x500	40	14	28

*The total volume of the cabinet is indicated
AD – solid insulation door.

Explanation symbols

Safety instructions and warnings are marked in this manual with symbols and signal words

Symbol	Explanation
 WARNING	Danger of medium degree. Can result in serious injury or death
 Attention	A hazard with a low degree of risk
 Notification	Individual information or general important information to avoid property damage
 Electric voltage	Risk of electric shock
 Flammable substances	Substances ignite from slight heating, a small source of fire
 Separate collection of electrical and electronic equipment	Special disposal - it is not allowed to be thrown out together with the rest of the waste, special conditions are required for recycling.

General information

This operating manual is part of the equipment and ensures safe and efficient operation.

Carefully read this instruction manual before using the equipment, and pass it on to other persons who are entrusted with the operation and maintenance of this equipment.

Make sure that the manual is read and understood by the people involved in the operation and maintenance of the equipment.

Make sure that the operating instructions are available and in an accessible place.

Only trained personnel may operate and clean the equipment. Only a qualified technician authorized by the manufacturer may carry out maintenance and repairs.

Manufacturer's responsibility

All information in this manual was compiled taking into account current standards and legal norms, as well as empirical values of the manufacturer. The manufacturer is not responsible for damage to people or property (equipment, goods, etc.) resulting from:

- Failure to comply with the instructions and safety rules contained therein
- Improper use
- Engagement of untrained operational and service personnel
- Unauthorized conversion and technical changes by the customer himself
- Use of spare parts not approved by the manufacturer

- Malfunction of the power supply or electrical safety devices

Failure to comply with the above points may also void the warranty.

The manufacturer reserves the right to make technical changes to optimize and improve the efficiency of the equipment.

General safety instructions and warnings



WARNING

- Never connect damaged equipment to the mains. In this case, immediately contact the manufacturer's service department. Otherwise, there is a risk of electric shock or refrigerant leakage.
- Do not use multiple outlet blocks or extension cords. Thermal overload occurs, creating a risk of smoldering/burning and electric shock.
- Do not under any circumstances remove the protective devices or covers attached to the device by the manufacturer. There is a risk of injury from moving parts or voltage.
- Do not make technical changes to the equipment. Otherwise, there is a risk of injury or electric shock.
- Damaged network cables can only be replaced by an authorized service technician. Otherwise, there is a risk of electric shock.
- Before starting work with the electrical system and the cooling system, it is necessary to disconnect the cable from the equipment network. Otherwise, there is a risk of electric shock.



Notification

- The equipment can be transported, stored and used only in a vertical position, standing on the rollers or legs intended for this purpose.
- Inspect the equipment for shipping damage and test it for functionality immediately after delivery. If you find any defects, contact the manufacturer's service department immediately.
- The equipment must be operated in the climate class indicated on the nameplate ([Fig. 1](#)). Operation above the values indicated in the climate class will lead to a decrease in energy efficiency and productivity.
- Do not expose the equipment to direct sunlight or high-temperature radiators.
- For the correct operation of the equipment, the ambient temperature should not be lower than +16°C and not exceed the temperature indicated on the nameplate ([Fig. 1](#)) of the climate class for which the equipment is intended.

Examples of climate classes

Climate class	Temperature, °C	Relative humidity, %
CC1	25.0	60
CC2	32.2	65
CC3	40.6	75

- The equipment works immediately after connecting to the electrical network. Any other use is considered inappropriate.
- The equipment is intended only for storing frozen products.
- In the event of a power outage, the stored goods must be checked by a responsible person.

- The door can be opened for a short time only to load and unload the product. After that, they need to be completely closed again.

1. Standards and directives

Product responds position following directives:

- Directive on machines, mechanisms and machine equipment 2006/42 / EU;
- Electromagnetic Directive compatibility 2014 / 30EU;
- Directive on low voltage equipment 2014 / 35EU.

Output products at the enterprise is carried out in an integrated management system in accordance with the requirements standards

ISO 9001:2015;

ISO 1400:2015;

ISO 45001:2018, IDT.

Standards used in the design and manufacture of products:

EN 1690 2 :2016

2. Rating plate

When working with the equipment, it is necessary to observe the information on the sign. This is a sticker on the back of the equipment that contains important technical data.

 ТОВ «ПІВ КІЛЬ», вул. Немурицьке шосе, 213, м. Вінниця, Вінницька обл., Україна 21034 GREEN COOL LTD, Nemurivske Road st., 213, Vinnytsia Vinnytsia reg., Ukraine, 21034			
2	Refrigeration bottle: Напій/Вуглець:	230V	Частота/ Frequency: 50Hz
4	Алюмінієвий/Протекція:	I	Потужність/ Power consumption: 437 W
6	Кліматичний клас/Climate class:	CC2	Маса нетто/ Net weight: 119kg±3%
8	Маса хладагенту/Refrigerant charge:	85 g	Колір хладагенту/ Refr. percent: R-290
10	Температурний клас всередині холодильної шафи/ Temperature class inside the refrigerator bottle		Температура/ Temperature: X4
12	Ступінь захисту/ Degree of protection		IP 21
14	Ім. №/Inv. №: 319027658	Дата/Date:	12.2022
13	Сериальний №/Serial No.: 4396522068	 	
15	1U Y 28.2-4046992-002.2022		16

Fig. 1. rating plate

1. Showcase name;
2. Voltage (V);
3. Frequency (Hz);
4. Protection class;
5. Maximum used power (W);
6. Climatic class of the showcase;
7. Net weight of the showcase (kg);
8. Refrigerant mass (g)
9. Refrigerant type;
10. Temperature class inside the showcase;
11. Inventory number;
12. Degree of protection;
13. Date of manufacture;
14. The serial number;
15. Country of manufacture and certification marks
16. Product conformity conditions;

3. Unpacking, installing and connecting

Before and during the unpacking of the equipment, it is necessary to conduct a visual inspection to detect possible damage during transportation. Pay attention to loose parts, dents, scratches, etc. If any damage is detected, it is necessary to notify the service department before putting it into operation.

The packaging protects the product from damage during transportation. Place the packaging in a suitable collection bin for recycling or return it for recycling, which helps to conserve raw materials and reduce waste.

If there are no such bins near your home, you can try to make a box yourself and put the waste in it, and then take it to special collection points yourself, or arrange for collection with a local waste carrier. In any case, remember that waste should be disposed of without bags, tapes, or other packaging, and try to dispose of it separately from general waste.

When installed, pay attention to the following points:

- Make sure that the equipment is installed stably and vertically.
- The ventilation holes (grid) of the equipment must be clean. Install the equipment in a well-ventilated area.
- When installing the equipment, observe minimum distances of at least 100 mm from walls and other equipment.
- Avoid drafts and excessive heat radiation at the installation site. Do not place the equipment near radiators, heaters, under air conditioners and ventilation ducts (inflow of warm

air when opening the door will increase the temperature of the product).

- Adjust the legs. After installation, lock the rollers (Fig. 2).



Fig. 2. Legs and a roller with a brake



Attention



Damaged equipment can cause a short circuit. Never plug in damaged equipment.

The device contains a small amount of environmentally safe but flammable gas R600, R290. Make sure that the cooling system components are not damaged during transportation, installation, etc. Gas leaks are not hazardous to the environment, but they can cause eye injury or fire.

In the event of accidental damage to the refrigerant circuit, avoid all open flames or potential sources of ignition and thoroughly ventilate the room where the refrigerated cabinet is located.

The minimum temperature of the equipment must be at least +16°C before commissioning.

The first connection of the equipment should be carried out no earlier than 1 hour after its installation. The first connection of the equipment should be made no earlier than 1 hour after installation. The coolant needs time to spread evenly around the refrigerator.

Before switching on the refrigerator, if it has been out of service for a long time, rinse it with warm water, wipe it dry and ventilate it for 50-60 minutes. Naturally, it must be unplugged before rinsing.

4. Temperature control

The display of the electronic temperature controller shows the internal temperature in equipment that is not directly related to the temperature of the product.

In the case of equipment without temperature indication, it is recommended to place the thermometer on the top layer of the product, but please note that it does not show the temperature of the product, but a slightly higher temperature.

Refrigerators are designed only for "+" (plus temperatures).

Depending on the field of application (purpose), different temperature classes are available.

Examples of temperature classes

Class	Minimum/maximum product temperature, °C	Average product temperature, °C
K ₁	0.0..+7.0	3.5
K ₂	-1.0..+6.0	2.5

K ₃	-3.5..+1.0	-1.0
K ₄	+1.0..+9.0	+5.0

5. Temperature regulator

The display temperature is set at the factory to maintain the temperature class/mode of the product specified by the manufacturer.

To ensure optimal storage temperature, it is recommended to save the settings.

A change in the temperature regime can lead to spoilage of the product.

Properly set temperature is very important for food storage. Microorganisms spoil food quickly, but you can prevent or delay this process by setting the right storage temperature. Temperature affects the rate of reproduction of microorganisms. Low temperature slows down these processes.

The temperature in the appliance rises if:

- the door is opened frequently and for a long time;
- there is a lot of food in the appliance;
- warm, fresh food is loaded for storage;
- the room temperature is high.

Lower room temperatures result in longer compressor downtime. This can lead to higher temperatures and damage.

5.1. Mechanical thermostat

The temperature regulator (thermostat) is located inside the cabinet on the ventilation grill (Fig. 3).



Fig. 3. Location of the thermostat inside the ventilation grill.

Thermostat settings:

Level 1: Less cold mode

Level 4: Factory settings (depends on the customer)

Level 7: The coldest mode

To set the desired temperature, turn the thermostat (plastic handle).

- along the time arrow of decreasing temperatures
- against a temporary increase in temperature

If you notice any signs of malfunction, you should contact the service center to have them diagnose and fix the problem with the refrigerator. However, before doing so, you can check the thermostat yourself.

How to check the refrigerator thermostat yourself, step-by-step instructions:

- Disconnect the refrigerator from the mains - this is necessary to completely de-energize the appliance;
- Move the product to a cabinet with a suitable temperature regime;
- Defrost the refrigerator - the chambers of the appliance should be completely thawed and the compressor should cool down;
- Put a thermometer in the volume of the refrigerator (ideally two thermometers at the same time) - you will need a thermometer to accurately determine the temperature inside;
- Set the temperature controller to the minimum value - turn the knob clockwise to the extreme position;
- Plug the refrigerator into the network and start it up - the chamber doors should be tightly closed for two hours of operation of the refrigerator;
- Check the temperature on the thermometers - the temperature in the refrigerator should be in the range of +1...+9°C

It is enough to put an outdoor thermometer on the shelf of the refrigerator. According to temperature measurement standards, you need to hold the thermometer for at least 10 minutes. Once you know how many degrees are on a particular shelf, you can keep food fresh and flavorful longer. This is because the temperature is unevenly distributed. The temperature will be higher near the door than near the back wall.





The closer you are to the place where the cold comes in, the cooler it is. The same principle applies to the freezer.

5.2. Eliwell electronic temperature controller

controller is placed on the front panel or inside the cabinet. Control elements are buttons (Fig. 4), which are programmed as follows:



Fig. 4 . Indication and control elements of the controller Eliwell .

Control element	Functions
 Above	Increase variable value Scrolling through menu items
 down	Decrement the variable value Scrolling through menu items
 Entrance	Return to the previous menu level Confirm the new value Long-term hold (5 sec .) Starting and exiting Standby mode
 Input	Display of accidents Opening the main menu Long-term hold (5 sec .) Opening the programming menu Command confirmation

Press the "Enter" button to display the set value.

Changing the set value:




1. Press the "Enter" button. The inscription " Set " will appear on the display .
2. Press "Enter" again, the display will show the set temperature.
3. Use the "Up"/"Down" keys to change the set value.
4. Press the "Enter" button to confirm the changes.


5.3. Danfoss electronic temperature controller



Fig. 5. Control elements of the Danfoss controller ERC 112.

Control elements are buttons programmed as follows:

Button	Function
	Short-term press: Increasing the set temperature (settings) Long press: defrost mode switch
	Short-term press: Decrease the set temperature (settings) Long press: defrost mode switch
	Short-term press: not used; Long press: Enter the information menu

	<p>Short-term press: light switch (option) Long press: on/off</p>
---	---

Changing the set temperature (setting) :

1. The display shows the current temperature in the middle
2. Press " Up /Down" to access the set temperature (settings)
3. Press " Up /Down" to change the set temperature (settings) After 30 sec. the display will automatically return to the current temperature.

5.4. Elitech electronic temperature controller



Fig. 6. Control elements of the Elitech controller

Control elements (Fig. 6)

Symbol	Function	Action
<p style="text-align: center;">Set</p>	<p>Changing the set temperature</p>	<p>Press and release</p>
	<p>Entering the administrator menu</p>	<p>Hold for 5s</p>
	<p>Entering the command confirmation menu</p>	<p>Click</p>
	<p>Increase in values</p>	<p>Click</p>

▲	Flipping through menu items	Click
▼	Reduction of values	Click
	Flipping through menu items	Click
❄	Exit the menu	Click
	Turning on defrosting	Hold for 3s

Changing the temperature regime:




1. Press and release " Set " to enter the user menu, the " set " indicator will light up and " SET " will be displayed
2. Press the " Set " key to display the current value of the set temperature
3. Press the ▲/▼ key to change the “ SET ” value
4. Press the key or ❄ wait 30 seconds to save the set value.

5.5. Carel electronic temperature controller



Fig. 7. Control elements of the Carel controller

Control elements

Symbol	Function	Action
	On/Off	Press and hold for 5 seconds
	Flipping through the menu options Increasing sizes	Press
	Turning on the defrost function	Press and hold for 5 seconds
	Scrolling through menu options Decrease values	Press
	Changing the set temperature	Press 3s
	Confirmation of changes	Press
	Access to the options menu	Press and hold for 5 seconds

Changing the temperature regime:

1. Click " Set " and hold for 3 seconds. The display will show the set temperature.
2. Use the "Up"/"Down" arrows to change the value you need.
3. Click " Set " to confirm the changes.
4. To exit the menu without saving the changed values, do not press any button for 60 seconds.



6. Lighting control (optional)


The RFMINI-01 controller is used to control the lighting.

With its help, you can change the brightness of the LED, as well as select the glow mode (static or dynamic)




Fig. 8. RFMINI-01 controller

Symbol	Function	Action
	Selecting the light mode	Press
	Change the light mode (in dynamic mode)	
	In dynamic light mode - speed change	Press
	In static light mode - change of brightness	Press

	Turning off the controller	Press 2s
	Switching to static light	Press

Typical wiring diagram:



7. Loading

Install shelves (Fig. 8) depending on the height of the product to be loaded (bottles, cans, etc.).



Fig. 9. Installation of shelf brackets.

Load the product into the refrigerator. It is recommended to load the cabinet at night so that the product is cooled in the morning.

It is recommended to store the product being loaded in a cool place so that it takes less time to cool down when loading.

8. Maintenance, defrosting and cleaning

The refrigerator defrosts automatically.

vacuumed once a year . If the refrigerating cabinet is located in a dusty and/or greasy environment, it is recommended to regularly clean the refrigerating unit.

Sharp objects will damage the cooling unit and cause damage to the appliance. Therefore, do not use sharp objects to:

- removing frost and ice;
- Separating frozen ice cube trays and food.

9. Service

It is recommended to clean the condenser at least once a month. To clean the condenser, it is necessary to dismantle the grilles (see Fig. 4) to gain access to the engine room.

Remove dirt (dust, fluff, etc.) from the surface of the condenser and install the grids back.

Failure to clean the condenser in a timely manner will result in malfunctioning of the compressor, increased temperature in the cabinet's

working volume, overheating of the compressor and its breakdown, and will also serve as grounds for refusal to fulfill the warranty.

Dust behind the refrigerator and on the floor should be cleaned regularly to improve cooling and save energy.

- If the recommendation is not followed, in the event of a breakdown, the manufacturer is not responsible.

Cleaning process:

1. Move the product to a refrigerator with the appropriate temperature regime.
2. Disconnect the power cable.
3. Open the lid for better defrosting.
4. Take out baskets or partitions.
5. Remove the melted water.
6. Remove any remaining product that has been stored.
7. Wash the equipment using the manufacturer's recommended detergents and equipment.
8. Wipe the device dry.
9. Put back the baskets or partitions.
10. Connect the power cable to the electrical network.
11. Wait for the required temperature to store the product.
12. The product can be stored again.

We recommend using detergents:

Detergent	Cleaning area
Clean water	External and internal surfaces of the equipment. External and internal glass surfaces

Detergents (eg soap and water) in case of heavy contamination	External and internal surfaces of the equipment. External glass surfaces
Windscreen wiper	External glass surfaces

When cleaning, use the following inventory:

Cleaning supplies	Cleaning area
Wet soft cotton fabric	External and internal surfaces of the equipment. External and internal glass surfaces
A damp absorbent cloth or sponge	External and internal surfaces of the equipment. External and internal glass surfaces
For drying	
Wet soft cotton fabric	External and internal surfaces of the equipment. External and internal glass surfaces

10. Storage

If you take the equipment out of operation for a long period of time, you must:

1. Take out all the goods.
2. Disconnect the power cable.
3. Open the door and allow the equipment to warm up to ambient temperature. Clean the equipment.

4. Open the door (about 2-4 cm). Ventilation prevents the formation of odors and spores inside.

11. Disposal



Improper disposal harms the environment.

Pay attention to the safe disposal of refrigerant, insulating foam (polyurethane foam), compressor oil, power supply unit.

Dispose of the equipment properly in accordance with applicable national disposal regulations and the regulations of your local disposal partner.

Devices cannot be disposed of together with household waste.

12. Information on the type of refrigerants and foam blowing agents

The refrigerant circulation enclosure has been tested for leaks. The appliance complies with the applicable technical safety standards and regulations.

The refrigerant used in the refrigerated cabinets is R600a (isobutane), which is a natural gas that is well compatible with the environment in terms of environmental protection, but at the same time it is a flammable gas. It does not deplete the Earth's ozone layer (ODP = 0) and does not contribute to the greenhouse effect.

The use of this environmentally friendly refrigerant is partly responsible for the increased noise during operation. This means that noise from the compressor running may be accompanied by noise from the

refrigerant flow in the cooling circuit. Unfortunately, this effect cannot be avoided, but it does not affect the performance of the appliance.

The refrigerant used in the cabinets is R290 (propane), which is the best choice for replacing R404A and R407C, taking into account the "green properties" (environmental friendliness). Propane's strengths are its thermodynamic properties, wide availability, low cost, compatibility with mineral and alkyl benzene oils and with all materials used in compressor and refrigeration systems. However, the flammability of this refrigerant can be an obstacle to wider use.

Chemical formula C_3H_8 (propane). It belongs to the group of (hydrocarbon refrigerants) HFCs. Ozone depletion potential ODP = 0, global warming potential GWP = 3. It is characterized by low cost and non-toxicity. When using this refrigerant, there are no problems with the choice of construction materials for compressor, condenser and evaporator parts. Propane is highly soluble in mineral oils. The boiling point at atmospheric pressure is -42.1 C . The advantage of propane is the low temperature at the compressor outlet.

2-component systems for the production of polyurethane foam (PU foam) consist of polyol (A) and isocyanate (B).

Isocyanate is the base, it is the same for most systems. Polyol is a component responsible for the characteristics of polyurethane foam (foaming rate, density, etc.).

The system is designed for the production of rigid polyurethane foams used in the manufacture of thermal insulation for commercial refrigerators and freezers.

13. Possible malfunctions and their elimination

If the refrigerator is not working properly or has broken down, check the following before calling for service.

Problem	Possible reasons	Elimination
The wardrobe does not work	The power cord is not connected	Connect the cord to the network
	There is no power in the outlet	Check the voltage in the electrical network
The cabinet does not cool	The cabinet was loaded with a warm product. Please note that warm products take some time to cool down	It is recommended to load the cabinet before closing or at night
	The cabinet is loaded in such a way that air circulation in the volume is blocked	Unload the top row of product on the top shelf.
	The door does not close tightly	Contact the service department for repair work
	The cooling system is not sealed	Contact the service department
The refrigerator makes noise	Loud metallic noise	Contact the service department
	Crooked floor	Level the cabinet by adjusting the legs
Water on the floor	The condensate drain is clogged	Unblock the drain hole
	The bathtub is leaking	Contact the service department

The lighting does not work	Lighting button in position "O"	Move the button to the "I" position
	The LED line or the power supply has failed	Contact the service department

Authorized service	
<p>Poland : UBC Logistyka Sp . z o. o BYKOW, UL. GAJOWA 5 55-095 MIRKOW Wojtek Rytkowski tel.:+48717400076 / tel . com.: +48603227267 e - mail : w.rytkowski@beer-co.com</p>	<p>Bosnia : NICROM COOLING DOO Milan Vrhovca 79, 79101 Prijedor , Republic of Srpska , BiH Dragan Tankosic tel . :+38752213213 e - mail : dragan.tankosic@nicromcooling.com</p>
<p>Czech : THERMOTECNIKA BOHEMIA sro Komenského 951, 664 53 Újezd u Brna Phone : +420 544 229 478 • Fax: +420 544 e-mail: servis@tcbohemia.com</p>	<p>Croatia , Slovenia : BEVERAGES SERVIS DOO Slavonska avenija 24/A, 10000, Zagreb , Croatia Endre Katona tel . :+385914390830 e - mail : endre.katona@beverages.hr</p>
<p>Slovakia : Chladservis KP, sro . Bottova 347/16 953 01 Golden Moravce phone : +421 903 119 163 e - mail : info@chladserviskp.sk</p>	<p>France : Interfroid services 143 Bd Pierre Lefauchaux - 72230 France Johann JOUANNEAU : 0243892926 e - mail : Johann.jouanneau@interfroidservices.fr</p>
<p>Hungary H- Villszer Szerviz Kft . Iroda / warehouse : 1151 Bp. Székely Elek street 9,. P6 warehouse mobile : (+36) 30 475 9621 e-mail: hvillszerszerviz@hvillszerszerviz.hu website: www.hvillszerszerviz.hu</p>	<p>Germany : KTO GmbH Alte Römerstraße 9, 56154 Boppard- Buchholz Simon Sass tel . : +49 06742804828 e-mail: Simon.Sass@KTOGmbH.de</p>

<p>Greece : PRATSAS CLIMA & COOLING MPIZANIOU 2, METAMORPHOSI ATHENS, GREECE e-mail: info@pratsas-clima.gr Phone: +30 213 035 5059</p>	<p>Lithuania, Latvia : FINNRIGA FINLAND OY Ruosilantie 14 B209 00390 Helsinki info@finnriga.com www.finnriga.com Aleksandras Starovoitovas +358 45 6345261</p>
<p>Bulgaria : Ice Technic Ltd 1225 Sofia 61 Zhelezopatna Str . Vladimir Dimitrov tel . : +359888629539 e- mail : vladimir@icetechnic.com</p>	<p>Italy : UNIOR Srl . Via Collodi , 4/g 40012 Calderara di Reno Bologna - Italy Luca Pancaldi tel . +39 051 6467027 (10 lines ra .) e - mail : l.pancaldi@unior-service.com</p>
<p>Serbia : COOL BEER DOO Crkvište 5a, 11210 Krnjača Duško Advised te+381654977001 dusko.radjen@coolbeer.co.rs</p>	<p>Romania : THERMOTECNIKA CROWN COOL RO: str Toplița , nr . 155, Miercurea Ciuc Tel . No. 0040726308953 Email service@tcromania.com</p>
<p>Ukraine : UBC Service Address : Kharkiv , Selyanka 110, Ukraine Contact person : Andriy Maydan Phone : +380503476869 e - mail : a.maydan@beer-co.com</p>	
<p>Manufacturer address: LLC "GREEN COOL", st. Nemyrivske Shosse, 213, Vinnytsia, Vinnytsia region , Ukraine.</p>	